

## Standard Small Enclosure Installation

### Installation Guidelines for Enclosures Sized 17" x 30" and Smaller:

#### 1. Prepare the Excavation

- 1.01 Excavate approximately 6 inches deeper than depth of the enclosure.
- 1.02 Add 6 inches of gravel or crushed rock for drainage.

#### 2. Place Enclosure in Hole

- 2.01 Top of enclosure should be at grade level.

#### 3. Fill and Compact Soil

- 3.01 Fill to grade level with cover in enclosure.

#### 4. Grade Adjustment

- 4.01 If grade level is raised later, a straight sided enclosure can be pulled up and bricked at the bottom on one or four sides to conform to the landscape.



Excavate 6 inches deeper than the depth of the enclosure and add 6 to 8 inches of gravel or crushed rock (1.02).



The top of the enclosure should be level with the grade (2.01).



Make sure the cover is on when filling around the enclosure (3.01).